



## XTREME TOWER PRODUCTS MIRROR BRACKET INSTALLATION INSTRUCTIONS



Included parts shown on left.

*Note: Mirror is only included if bracket is specifically purchased with a mirror. Bracket works with CIPA 7' x14" mirror with a round clamp opening on the back.*

Necessary tools:  
5/16 Allen wrench  
5/32 Allen wrench



1. Attach rod to mirror bracket using the smaller thin bolts and a 5/32 Allen wrench. *Note: The bolts will only go into the bracket on one side so flip bracket over if they will not insert easily.*
2. Completely loosen the 1/2" bolt on the bottom of the mirror.
3. Insert mirror rod into the clamp on the mirror until the clamp stops on the milled ridge. *Note: You might need to use some WD-40 or baby powder and twist it back and forth for this to slide more easily.*
4. Gently tighten the 1/2" bolt on the bottom of the mirror. *Do not over tighten or the plastic clamp will break.*



5. Mount clamp on tower in desired position using the two larger bolts and a 5/16 Allen wrench. Alternately tighten the top and bottom bolts a little at a time so the clamp keeps a symmetrical shape. *Note: The clamp will not completely close around the pipe or tubing. There will be a small gap. Bracket should not twist on the tubing/pipe after tightening.*

6. Adjust clamp and mirror to desired viewing position.
7. Check bolts often and retighten periodically to ensure a secure hold.

Register your product at [www.xtremetowers.com](http://www.xtremetowers.com) and then enjoy your ride!

If you have any questions about this product,  
please contact us at [xtip@xtremetowers.com](mailto:xtip@xtremetowers.com) or call 877-5-TOWERS.  
See other great products at [www.xtremetowers.com](http://www.xtremetowers.com).