



K-Comp Tower Speakers Installation Instructions and Owners Manual

Monster Tower, Inc.
1205 Alpha Drive
Alpharetta, GA 30004

Phone: 877-77-Tower or 770-410-3451
Fax: 877-232-6538 or 770-234-3833
www.MonsterTower.com
Support@MonsterTower.com

THANK YOU FOR YOUR BUSINESS. IF YOU ARE NOT COMPLETELY SATISFIED IN ANY WAY WITH YOUR NEW SPEAKERS, PLEASE CONTACT US. Our entire purpose as a company is to offer great products at affordable prices that our customers love.


Please take a few minutes to read the installation instructions and become familiar with the speaker and installation before beginning to ensure a high quality, trouble free installation and use. If you have any questions during your installation give us a call at 877-77-Tower or e-mail Support@MonsterTower.com

NOTES ON INSTALLING AND USING YOUR NEW SPEAKERS

- For best performance, provide 100W-RMS at 4 Ohm to each speaker
- Regularly check all hardware to make sure it is tight
- Although the speakers are weather resistant and designed for outdoor use, do not spray directly into the grill with high-pressure water
- Handle the speakers with care as the enclosures can be damaged if dropped
- You will need two sets of wires for each speaker, one for the speaker and one for the light. We recommend 16 gauge 4 conductor wire
- If you have any further questions about wiring not covered in this manual please consult with a specialist in the area.

K-Comp Speaker Parts List and Assembly Diagrams

Item	Qty	Description
1	2	Tower Bracket
2	2	Collar Insert
3	2	NL-4 Connector
4	2	Enclosures
5	2	Speakers



Assembly Instructions

STEP 1: Attach the Collar Bracket (Item 1) to the tower using the Collar Inserts (Item 2) that matches your size tower. Tighten to 20 ft-lbs. Speakers should only be placed hanging down from the tower. The clamp is not designed to be a base support for the speaker.



STEP 2: Attach your speaker and light wires to the NL-4 connectors.

Make sure and leave enough wire to run from the connector to the amp or the electrical panel (or switch) for the light. Slide the wire holder and connector backside onto the wire (as shown below).



Strip the ends of the wires, and tighten into the corresponding (+) and (-) sockets. Speaker wires are connected to 1+ and 1- Light connections are 2+ and 2- . Connector locations are marked next to the screws on the connector.

STEP 3: Slide the connector backside over the wire holder and tighten.

STEP 4: Run the wires from the speakers to the connection point in the boat. This can be done by zip tying the wires to the outside of the tower, or by drilling a few holes and running the wires through the tower. Please consult your tower instruction manual on where to drill as different towers have different ways you have to run the wires. Connect all of your wires in the appropriate places in the boat. If you need help hooking your speakers and lights up in your boat please consult a specialist in the area.

STEP 5: Plug the NL-4 connectors into the speakers and go wakeboarding!

For further wiring / setup instructions please see next page.

Monster Tower, Inc. Warranty for Speaker Products

Monster Tower warrants this product **(not including the Speaker)** against manufacturers defects for a period of five (5) years. **The Speaker is covered by the manufactures warranty.** Anodized and Chrome plated surfaces are specifically excluded, as their care and use cannot be controlled by the manufacturer. Any modifications or improper use, not approved in writing by Monster Tower, shall void this warranty. Monster Tower is not responsible for personal injury or damage to the boat caused by the use of this product. Monster Tower's obligation under this warranty shall not include any transportation charges or costs of installation or any liability for direct, indirect or consequential damages resulting from delay or improper installation. If you need to make a warranty claim contact Monster Tower at 877-77-Tower to receive a return authorization, number which is required for all claims. Defects must be reported within 30 days of discovery.

Wiring Instructions and Amplifier Considerations

We recommend you use 16 to 18 gage wiring between the speakers and amplifier. Consult your tower installation manual or provider for instructions on running wire inside your tower. We recommend covering the wiring with 3/8" or 1/2" wiring loom and electrical tape as shown for a professional, watertight appearance.

The most common way to wire a boat with tower speakers is with the front speaker or front pre-amp outputs of the stereo driving all speakers in the boat. The rear speaker or rear pre-amp outputs are then used for the tower speakers. This allows the fader to control the volume from inside to behind the boat.



A four-channel amplifier in the boat is typical with two channels driving the boat speakers and two channels driving the tower speakers. The next level is to have separate amplifiers for the boat and for the tower speakers. We recommend supplying 100 RMS at 4 Ohms to each speaker. The peak power of an amplifier is what is advertised, but is also often misleading. The RMS at a specific Ohm Load is the real working power of the amplifier. It is generally agreed by audiophiles that supplying too much power to speakers is far better than under powering the speakers. If there is too much power the signal "clips off" and the speakers let you know with no damage. With too little power, you send lots of distortion to the speaker, which causes speaker damage. It's far better to "over amp" the speakers and not turn it up all the way than "under amp" them and send up damaging distortion.

Most amps have a Bass boost or filter that you can use to remove or add Bass. Turn this off or put on the lowest setting to remove as much Bass as possible to the tower speakers. If your amp has a High Pass Filter turn it to the highest frequency that sounds good to filter out as much Bass as possible. The Bass uses the majority of the amplifier power with sound that will not reach the rider. Mostly high frequency and upper mid-Bass will be audible at 65'-80' behind the boat over engine, water and wind noise.

For learning more about tower audio, we highly encourage you to visit the "Boats and Accessories" discussion boards at www.Wakeboarder.com and www.WakeWorld.com. We also support a website at www.diyTower.com that has a wealth of information on tower audio.